

Chin Spoiler Install for your 2011 Dodge Charger

Written by Lance

Monday, 10 October 2011 21:19 - Last Updated Thursday, 13 October 2011 08:28

The 2011 Chargers are great looking cars. One of the subtle modifications you can make to enhance the appearance of your Mopar is to add on a Chin Spoiler. This article, courtesy of Dave (4gtwrk) will walk you through the necessary steps to complete the upgrade.

Car: 2011 Toxic Orange Dodge Charger R/T

Part: 2011 Charger Chin Spoiler, PN 82212340

Tools: Tape, Sharipie, Tape Measure/Ruler, Drill, 1/4" Spur Drill Bit, Hand Rivet Gun (due to low clearance)

Install Time: 1 Hour

Difficulty: 2 Stars, just exercise caution!

Many thanks to Dave for the great write-up and pictures. Should be a big help to Charger owners looking into tackling this modification.

I added a chin spoiler to Kathy's Charger today and thought I'd take a few pictures during the process to help anyone else that wants to do it someday.

I purchased part #82212340, spoiler for a 2011 Charger.

Here's the front of the car stock.

Chin Spoiler Install for your 2011 Dodge Charger

Written by Lance

Monday, 10 October 2011 21:19 - Last Updated Thursday, 13 October 2011 08:28



10/08/2011

Tools needed: Drill, 1/4" drill bit, masking tape, Sharpie pen, ruler, Pop rivet gun



10/08/2011

With this bit I used a spur bit used for wood work to prevent splintering and it work great for



10/08/2011

With the full hole you spin as a gauge to see the placement so the edge is first it does not flip

Chin Spoiler Install for your 2011 Dodge Charger

Written by Lance

Monday, 10 October 2011 21:19 - Last Updated Thursday, 13 October 2011 08:28



Chin Spoiler Install for your 2011 Dodge Charger

Written by Lance

Monday, 10 October 2011 21:19 - Last Updated Thursday, 13 October 2011 08:28



agreed to be, its time to do that in before you

Here's the finished project;

